

A Word of Caution

Do not attempt installation of the power module into the rack without first:

1. Determining the output voltage of the power module
2. Determining the proper positioning of the key within the rack

When facing the front of the rack:


12VDC power modules – place key in far right position

24VDC power modules – place key in middle position

36VDC power modules – place key in far left position

48VDC power modules – place key in far left position

This is the key-



Key location:

