

Quick Start Guide SABRE Board for Smart Devices

Based on the iMX 6 Series



FREEDOM DEVELOPMENT PLATFORM



ABOUT THE SABRE BOARD FOR SMART DEVICES BASED ON THE I.MX 6 SERIES

The Smart Application Blueprint for Rapid Engineering (SABRE) board for smart devices introduces developers to the i.MX 6 series of applications processors. Designed for ultimate scalability, this entry level development system ships with the i.MX 6Quad applications processor but is schematically compatible with i.MX 6Dual, i.MX 6DualLite and i.MX 6Solo applications processors. This helps to reduce time to market by providing a foundational product design and serves as a launching point for more complex designs. Included with the design are links to the hardware design files, tools and board support packages (BSP) for Linux[®] and Android™ along with a bootable Android image on an SD card to get you up and running quickly.





The following features are available with the SABRE board for smart devices:

- ▶ i.MX 6Quad applications processor
- 1 GHz
- ▶ 1 GB DDR3, 533MHz
- ▶ 8 GB eMMC iNAND
- Two SD card slots
- SATA 22-pin connector
- HDMI connector
- Two LVDS connectors
- ▶ LCD expansion port connector
- Serial camera connector

- Two 3.5 mm audio ports (stereo HP and microphone)
- USB OTG connector
- Debug out via USB µAB device connector
- Gigabit Ethernet connector
- JTAG 20-pin connector
- mPCle connector
- Sensor package including:
 - 3-axis accelerometer
 - Digital compass



GET TO KNOW SABRE BOARD FOR SMART DEVICES BASED ON THE i.MX 6 SERIES



*Board also includes Bluetooth® Connector J13







GETTING STARTED

This section describes how to use the SABRE board for smart devices and the components in the kit. This section also describes the PC requirements to develop applications using the SABRE board for smart devices.

1 Unpacking the Kit

The SABRE board for smart devices is shipped with the items listed in Table 1. Ensure the items listed in Table 1 are available in the i.MX 6 series development kit. Remove the board from the antistatic bag and perform a visual inspection.

DESCRIPTION
i.MX 6 SABRE board for smart devices
USB cable (micro-B to standard-A)
5 V/5 A universal power supply
Quick Start Guide (this document)
Bootable demonstration code for smart device platform

Table 1: SABRE Board for Smart Devices Based on i.MX 6 Series Development Kit Contents







"JUMP START YOUR DESIGN" CONTENTS

ITEM	DESCRIPTION
SABRE board for smart devices documentation	 Schematics, layout and Gerber files
	 SABRE board for smart devices quick start guide (this document)
Software development tools	Android and Linux board support packages
SABRE board for smart devices demo images	Copy of the Android image provided on the SD card

Table 2: "Jump Start Your Design" Contents



SETTING UP THE SYSTEM

1 Insert SD Card

Insert the supplied SD card into socket SD3.

2 Connect USB Debug Cable (Optional)

Connect the micro-B end of the supplied USB cable into debug port J509. Connect the other end of the cable to a PC acting as a host terminal. If needed, the serial-to-USB drivers can be found at ftdichip.com/FTDrivers.htm.

Terminal window configuration: 115.2 kbaud, 8 data bits, 1 stop bit, no parity

3 Connect HDMI Cable

Connect an HDMI cable to the HDMI connector J8. Connect the other end to the HDMI cable to an HDMI capable monitor.

4 Connect User Interface Devices

Attach a keyboard and mouse to interact with the Android OS displayed on the monitor. Attach a USB hub to USB jack J505 and connect the keyboard and mouse to the hub. If only one device is used, it can be plugged directly into the USB jack. A micro B male to A female adapter cable may be needed.

5 Connect Ethernet Cable (optional)

Connect an Ethernet cable to the Ethernet jack J7.

6 Connect Power Supply

Connect the 5 V power supply cable to the 5 V DC power jack P1. When power is connected to the smart device, it will automatically begin the boot sequence.



BOOT PROCESS FOR ANDROID IMAGE

Boot Process

- During the boot process, there will be operating system status information scrolling on the terminal window of the PC (if connected). The Linux penguin images will initially appear in the upper left corner of the display, one for each operating ARM[®] core.
- When the boot process is complete, the Android operating system will be displayed.
- To work from the terminal window on the host PC, press enter at the terminal window to get the command prompt.

DIP SWITCH CONFIGURATION

Table 3 shows the jumper configuration to boot the smart device from SD card slot SD3.

DIP SWITCH CONFIGURATION (SW6)

D1	D2	D3	D4	D5	D6	D7	D8
Off	On	Off	Off	Off	Off	On	Off

Table 2: "Jump	Start Your	Design"	Contents
----------------	------------	---------	----------



SWITCH FUNCTIONS

Table 4 shows the functions of the five pushbutton switches on the board.

BUTTON OPERATIONS

ITEM	DESCRIPTION
	SABRE board POWER button
POWER SW1	Momentary depress of button will place the system in standby.
	 Long press of the button will display a software drive shutdown option menu.
	 Prolonged depress (> 5 sec) will force an immediate hardware shutdown.
	If board is in the OFF state, momentary depress of button will restart (boot) the system.
	 If board is in the STANDBY state, momentary depress of the button will bring the system out of standby (resume operations, no boot)
	SABRE board RESET button
RESET SW2	Momentary depress of button will reset the system and begin a boot sequence.
	SABRE board shutdown switch
SHUTDOWN SW3	 Sliding the switch to the O position connects the 5 V power supply to the SABRE board main power system.
	 Sliding the shutdown switch immediately removes all power to the board.
Volume up SW4	Volume +
Volume down SW5	Volume -

Table 4: SABRE Board for Smart Devices Button Operations







יזשע זישע. וואני זישע זישעייט אישעייט איש

WARRANTY

Visit **www.nxp.com/warranty** for complete warranty information.

Get Started Download installation software and documentation under "Jump Start Your Design" at www.nxp.com/SABRESDB.

www.nxp.com/iMXSABRE

All other product or service names are the property of their respective owners. ARM is a registered trademark of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. © 2012, 2014–2015 Freescale Semiconductor, Inc.

Document Number: IMX6QSDBQSG REV 2 Agile Number: 926-27516 REV C